Installation Instructions

SJ8QGRN Refrigeration Package

NOTICE: This water cooler must be connected to the water supply using a dielectric coupling.


IMPORTANT! INSTALLER PLEASE NOTE.

The grounding of electrical equipment such as telephone, computers, etc., to water lines is a common procedure. This grounding may be in the building, or may occur away from the building. This grounding can cause electrical feedback into a water chiller, creating an electrolysis which causes a metallic taste or an increase in the metal content of the water. This condition is avoidable by using the proper materials indicated below.

Uses HFC-134A refrigerant (25mm) 10 3/8" (263mm) (51mm) B (338mm) 3 3/8" (426mm) 16 3/4" (426mm)

LEGEND

A = 1/4" O.D. TUBE WATER OUTLET B = 1/4" O.D. TUBE WATER INLET C = TEMPERATURE ADJUSTMENT D = ELECTRICAL



Note: Danger! Electric shock hazard. Disconnect power before servicing unit.

INSTALLATION

- 1. When mounting unit in an open area, to insure proper ventilation, maintain a 4" (102mm) clearance from cabinet louvers on each side of cooler . When mounting unit in a cavity or behind a wall maintain minimum space of 4" (102mm) on each side, 4" (102mm) on the top and a depth of 12" (305mm).
- Water inlet is 1/4" (6 mm) O.D. tube. Contractor to supply the connections as required.
- 3. Connecting lines to be of unplated copper, thoroughly flushed to remove all foreign matter before being connected to cooler. If flushing does not remove all particles, a water strainer should be installed in supply line. This cooler is manufactured in such a manner that it does not in any way cause taste, odor, color or sediment problems.
- 4. Connect cooler to building supply line with a shut-off valve and install the in-line strainer between the valve and cooler.
- Electrical: Make sure power supply is identical in voltage, cycle, and phase to that specified on cooler serial plate. Never wire compressor directly to the power supply.
- 6. This chiller has been designed for use with potable water ONLY.

START-UP

- 1. Open supply line valve.
- Purge air from all water lines by operating bubbler valve of fountain to which cooler is connected. Steady stream assures all air is removed.
- 3. Rotate fan to insure proper clearance and free fan action.
- 4. Connect to electrical power.

TROUBLE SHOOTING & MAINTENANCE


Temperature Control: Factory set at 50°F (± 5°) under normal conditions. For colder water, adjust screw on item no. 12 in clockwise direction

Ventilation: Cabinet louvers and condenser fins should be periodically cleaned with brush, air hose or vacuum cleaner. Excess dirt or poor ventilation can cause no cold water and compressor cycling on the compressor overload protector.

Lubrication: Motors are lifetime lubricated.

Actuation of Quick Connect Water Fittings: Cooler is provided with lead-free connectors which utilize an o-ring seal. To remove tubing from the fittings, relieve water pressure, push in on gray collar while pulling on the tubing. To insert tubing, push tube straight into fitting until it reaches a positive stop, approximately 3/4".

OPERATION OF QUICK CONNECT FITTINGS




98664C (Rev. C - 10/16)


SJ8QGRN*1B


115V ITEMIZED PARTS LIST		
ITEM NO.	PART NO.	DESCRIPTION
1 2 3 4 5 6 7 8 9 10 *11 12 13 14 15 16 17	000000745 28478C 98776C 98775C 20282C 22300C 55996C 1000001602 98778C 66703C 0000000768 35839C 28477C 98750C 50930C 27303C	KIT - EVAPORATOR TANK ASSY CABINET KIT - CONDENSER/DRIER KIT - FAN MTR/BLADE/SHROUD/SCREWS/NUTS BRACKET - FAN MOUNTING PANEL - REAR IN-LINE STRAINER KIT - ELBOW 5/16" x 1/4" (3 PACK) KIT - HEAT EXCHANGER/DRIER DRIER COMPRESSOR SERVICE PAK COLD CONTROL PANEL - FRONT KIT - ELEC/RELAY/OL/CAPACITOR/COVER BUMPER BASEPLATE KIT - COMPR MTG/STUDS/CLIPS/GROMMETS

*INCLUDES RELAY & OVERLOAD. IF UNDER WARRANTY, REPLACE WITH SAME COMPRESSOR USED IN ORIGINAL ASSEMBLY.

NOTE: All correspondence pertaining to any of the above water cooler or orders for repair parts MUST include model number and serial number of cooler, name and part number of replacement part.







WIRING DIAGRAM

Halsey Taylor 2222 CAMDEN COURT

2222 CAMDEN COURT OAK BROOK, IL 60523 630.574.3500

PRINTED IN U.S.A.

FOR PARTS CONTACT YOUR LOCAL DISTRIBUTOR OR VISIT OUR WEBSITE WWW.HALSEYTAYLOR.COM

98664C (Rev. C -10/16)