

# INSTRUCTION SHEET - 97258C CANE APRON KIT

## For use with Contour® and Soft Sides® models

1. REMOVE (5) SCREWS AND BOTTOM COVER PLATE.
2. ATTACH (ITEM 1) CANE APRON WITH THE (5) SCREWS PROVIDED.
3. BOTTOM COVER AND ORIGINAL SCREWS CAN BE DISCARDED.

KIT CONSISTS OF:

| ITEM | PART NO. | DESCRIPTION     |
|------|----------|-----------------|
| 1    | 56020C   | CANE APRON      |
| 2    | 75740C   | SCREW #10 X .50 |

