
Installation and Maintenance Guide



Elvari™ Toilet Seat Cover Dispenser, Surface-Mounted

Model 5B1-11

Table of Contents

Safety Information	2
Dimensions Installing the Toilet Seat Cover Dispenser	



Scan or click code to view Installation Guide (English)



Scan or click code to view Installation Guide (French)



Scan or click code to view Installation Guide (Spanish)



Read the instructions in this manual before beginning installation.

Save these instructions and refer to them for operation and maintenance information.

For questions regarding the operation, installation, or maintenance of this product, visit bradleycorp.com or call 800.BRADLEY (800.272.3539). Product warranties and parts information may also be found under "Resources" on our website at bradleycorp.com.

P20-257 Rev. A: ECO 22-15-012 © 2023 Bradley

Page 1 of 3 10/15/2023





Safety Information



Toilet seat cover dispensers are no stronger than the anchors and walls to which they are attached, and therefore, must be firmly secured in order to support the intended load requirements. To avoid potential injury, the building owner or maintenance personnel should remove the dispenser from service if the mounting is not adequately secured to the wall or if there are any observed product defects.


IMPORTANT

Read this entire installation manual to ensure proper installation. When installation is complete, file this manual with the owner or maintenance department. Compliance and conformity to local codes and ordinances is the responsibility of the installer.


Separate parts from packaging and make sure all parts are accounted for before discarding any packaging material. If any parts are missing, do not begin installation until you obtain the missing parts.

Dimensions (mm)

Medium Capacity



Large Capacity



ADA maximum dispense height is 48" (1219). See ADA mark for location.

2

Installing the Toilet Seat Cover Dispenser



Coordinate installation with architect and contractor to avoid protrusion from opposite wall or pipes, vents, conduits, electrical wiring, etc., in wall.

Follow all applicable local building codes. If installing where unit projects above top of wainscot, provide aluminum channel or other filler to prevent gap from finished wall and flange of unit. For block walls, use metal expansion shields (not included).




Drill the mounting holes and set the anchors (not included) per the mounting hole locations shown in the dimension illustrations on the previous page.




Position the dispenser on the wall and use appropriate fasteners (not included) to secure in place (x2 for medium capacity, x4 for large capacity).

Medium Capacity Dispenser



Large Capacity Dispenser



Cleaning and Maintenance

Scan or click the QR code below to view the Stainless Steel Washroom Accessories document.

